

GM Passlock II System Remote Starter Wiring Diagram for Basic Installation

Version 1.0.1
Pro88.car@gmail.com
<https://sites.google.com/site/pro88car/>

NON LIABILITY NOTICE:
AUTHOR SHALL NOT BE LIABLE FOR ANY DAMAGES SUFFERED AS A RESULT OF USING OR DISTRIBUTING THIS DIAGRAM. IN NO EVENT WILL AUTHOR BE LIABLE FOR ANY LOST REVENUE, PROFIT OR DATA, OR FOR DIRECT, INDIRECT, SPECIAL, CONSEQUENTIAL, INCIDENTAL OR PUNITIVE DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF THE USE OF OR INABILITY TO USE THIS DIAGRAM, EVEN IF AUTHOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

